

- System
- Network
- Firewall

- Access Rules
- Advanced
- Services
- VoIP**
- Connections Monitor

- VPN
- Users
- Security Services
- Log
- Wizards
- Help
- Logout

General Settings

Enable consistent NAT

SIP Settings

Enable SIP Transformations

Permit non-SIP packets on signaling port

SIP Signaling inactivity time out (seconds):

SIP Media inactivity time out (seconds):

Additional SIP signaling port (UDP) for transformations (optional):

H.323 Settings

Enable H.323 Transformations

H.323 Signaling/Media inactivity time out (seconds):